

ALUMINIUM VENETIAN BLINDS INSTALLATION

INSTALLING YOUR BLINDS IS EASY WITH OUR SIMPLE INSTALLATION GUIDES!

ITEMS DELIVERED AS PART OF YOUR PACKAGE:

- **Venetian Blind**
- **Brackets and Screws**

TOOLS REQUIRED:

- **Cordless drill with appropriate drill bit**
- **Pencil**
- **Tape Measure**
- **If blind is particularly large have someone help you lift and secure in place.**

GO TO PAGE 2 FOR INSIDE THE FRAME INSTALLATION.

GO TO PAGE 4 FOR OUTSIDE THE FRAME INSTALLATION.

ALUMINIUM VENETIAN BLINDS INSTALLATION INSIDE FIT

STEP 1 INSIDE WINDOW FIT



- Carefully remove bubble wrap and plastic from blind, release brackets and screws.
- Using a metal tape measure and pencil mark 9cm and 12cm in from the inside edge of the frame.
- Repeat at the opposite end.
- Place the brackets in the middle of the marks and screw into place.



- For blinds requiring more brackets space them evenly making sure they don't interfere with the tape rolls inside the headrail.

STEP 2 INSIDE WINDOW FIT



- Now that your brackets are evenly secured inside your frame, pick up your Venetian blind, it must be in the up position so leave it pulled up like it came in the packaging.
- Look down into the tracks headrail, notice the track profile and how the brackets will hook/click into place.

STEP 3 INSIDE WINDOW FIT



- This is how it should look once completed. Pull the cords toward the middle of the blind, this releases the cord lock allowing you to lower the blind. Use the wand to control the angle of the slats.

ALUMINIUM VENETIAN BLINDS INSTALLATION OUTSIDE FIT

STEP 1 OUTSIDE WINDOW FIT



- Carefully remove bubble wrap and plastic from blind, release brackets and screws.
- Starting from the left side of the frame, using a metal tape and pencil make a mark at 85mm in from the outside edge of the frame.
- Repeat at the opposite end.
- Pre-drill your holes using a 4mm drill bit so you don't spilt any timber framework.
- Place the brackets in the middle of the marks and screw into place.



- For blinds requiring more brackets space them evenly making sure they don't interfere with the tape rolls inside the head rail.

STEP 2 OUTSIDE WINDOW FIT



- Now that your brackets are evenly secured to your frame, pick up your Venetian blind, it must be in the up position so leave it pulled up like it came in the packaging. Look down into the tracks headrail, notice the track profile and how the brackets will hook/click into place.
- On the inside front of the headrail at the top there is a lip. Hook this lip over the front of the bracket then push the back of the headrail up into the bracket until you hear it click into place for each bracket.

STEP 3 OUTSIDE WINDOW FIT



- This is how it should look once completed. Pull the cords toward the middle of the blind, this releases the cord lock allowing you to lower the blind. Use the wand to control the angle of the slats.